


Wiring diagram M76361, M76371



The switches are shown in the non-operated state

WE Travel switch
DE Torque switch
HZ Space heater

ESR Electronic position transmitter
POT Potentiometer

RSW Roller-type counting and switching mechanism
NSW Cam-type counting and switching mechanism